



Baxtran
BFN

**PORTABLE
BENCH
SCALE**

Bench scale with wheels and handles to facilitate mobility. Includes pivoting wheels with brake to avoid movement during the weighing process. Available with legal metrology.



**BACK PIVOTING
WHEELS WITH BRAKE**



INDICATOR WITH BATTERY



STRUCTURE DETAILS

FEATURES

- 4 wheels of 70 mm in diameter. Two fixed wheels on front and two rotatable wheels on rear with brakes.
- Tubular structure in powder-coating finish steel.
- Stainless steel pan.
- Legal metrology available.
- Handles for an easy transport.

Dimensions (mm):



INDICATOR BR16:

- Weight-tare indicator.
- ABS housing. IP54 protection.
- Waterproof keyboard with 6 keys of functions and switch on and switch off keys.
- Backlight LCD display with 6 digits of 40 mm.
- Backlight of the display with 3 types: automatic, activated and deactivated.
- ABS support for column.
- holes for wall anchor included.
- Blister included.
- Up to 4 load cells of 350 Ω each one or 8 load cells of 700 Ω .
- Operating temperature range: -10°C $+40^{\circ}\text{C}$.
- Power supply with adaptor AC/DC 240 Vac 50 Hz.
- Rechargeable Internal battery 6V / 4Ah.
- Battery life with activated back-lightning and RS-232 ON: 80 hours approx.
- Battery life with back-lightning disabled and RS-232 OFF: 320 hours approx.
- Units: kg o t o g (to choose at time of purchase order).
- Optional RS-232 output with PC and printer format.
- Unique range/Multi range (to choose at time of purchase order).
- Auto switch off (programmable from 1 to 99 minutes).
- Approval type at 3000 divisions OIML class III.
- EC approval.

FUNCTIONS:

- Accumulation
- Totalization
- Piece counting
- Zero
- Four modes of hold: deactivate, animal in motion, peak value, stable weight and stable weight with auto cancel in zero
- Control of weight and pieces (limits function) with visual signal and alarm
- Three speeds of the converter AD (high, medium and low)
- Gross/net
- Tare

INDICATOR KEYBOARD FUNCTIONS:

- Selecting weight units. Gross/net. Accumulation and manual data transmission to PC or printer; zero or tare. Separate keys for switch on and switch off.

MEANS OF SENDING DATA TO PC'S OR FOR PRINTING:

Printing formats (weight or pieces):

Simple print: weighing number and weight. Total number of weighed items and accumulated weight.

S/N	WT/KG
0001	0.64
0002	0.70
0003	0.64
0003	1.98

Ticket number printing. Gross. Tare. Detailed ticket number and weight printing.

```
TICKET NO.0003
G 0.64kg
T 0.00kg
N 0.64kg
```

Total number of tickets 0003

```
NET 1.92
```

Means of sending data to PC (weight or pieces):





Continuous sending without accumulation; with weight stability and sending without accumulation via manual mode.

Two formats of 8 digits including sign and decimal point if it is required.

Format 1: Stable/Unstable, gross/net, weight/pieces with sign and unit.

Format 2: Weight/Pieces with sign and unit.

References

	Code	Pan (mm)	Capacity (kg)	Readout (g)	Readout CE-M (g)	Packing dimensions (mm)	Packing weight (kg)	ENAC certifications
	261080	800x600	300	50	-	1215 x 745 x 190	45	900002
	261081	800x600	500	100	-	1215 x 745 x 190	45	900002
	261082	800x600	300	-	100	1215 x 745 x 190	45	900003
	261083	800x600	500	-	200	1215 x 745 x 190	45	900003

Accessories

Code	Description
BFN232	RS232 output
IMP05	Printer